1

PR0165SL/SLE Series

Mechanical Bearing, Ball-Screw Stage

Improved second-generation design

High-performance in a cost-effective package

Rugged mechanical construction

Optional linear encoder

18 models with travels from 50 mm to 600 mm

Vacuum and cleanroom versions available

Available with built-in ThermoComp™ for highperformance in changing environments

The PRO165SL and PRO165SLE are Aerotech's secondgeneration PRO165 stage designs with many improvements and added features. Enhanced positioning specifications coupled with competitive pricing make the PRO165SL/ SLE stage the ideal choice for both medium and highperformance applications. The design is similar to the PRO115SL/SLE series, providing additional load capacity and stiffness with larger bearings and a wider cross-section.

Rugged Mechanical Construction

A long-life recirculating linear guide bearing system and a low-friction sealing solution make the PRO165SL/SLE an attractive solution for industrial applications such as laser machining. The basic external construction of the PRO165SL/SLE design provides protection from debris while the side-seals prevent dirt and particulates from entering the stage. The curved hard-cover design provides a natural shape that prevents excessive debris from collecting on the stage.

Linear Encoder Option

For applications requiring direct-metrology of the output carriage, the PRO165SLE integrates a direct linear encoder that is protected by the stage sealing system. Amplified sine, digital TTL output, and absolute encoders are available as standard options for linear feedback.

Design and Integration Flexibility

The PRO165SL/SLE is designed with many standard features and options that make the design incredibly flexible and allow it to be easily tailored to a specific application. The PRO165SL/SLE is available in 18 different models with travels ranging from 50 mm to 600 mm and speeds up to 300 mm/s.

PRO Series Gen II

Up to:

98% Higher Resolution

46% Better Repeatability

40% Reduction in Error Motions

33% Improved Accuracy

Available with ThermoComp®



The base mounting holes are accessible from the outside of the stage allowing for easy mounting. Standard mounting holes for both English and metric optical tables are present in all travels. The tabletop is available with both English and metric mounting patterns and can be ordered with brush attachments to clear any debris that may collect on the stage hard cover. Tabletops with hole patterns that allow the direct attachment of Aerotech's ADRS, ACS-LP, ADRT, ACS, and AGR rotary stages are also available.

Aerotech BM or BMS series brushless servomotors are available with a variety of encoder options providing net electronic resolutions ranging from 0.5 µm down to subnm. A holding brake can be added to the motor for vertical applications. A motor foldback kit is available for spaceconstrained applications to reduce the overall stage length.

The PRO165SL/SLE series is also available with cleanroom preparation and vacuum versions.

Accurate Positioning with ThermoComp

Temperature changes and thermal effects are some of the largest error sources in precision machines, particularly in ball-screw-driven mechanics due to self-heating. All PRO series stages are available with Aerotech's ThermoComp feature, an embedded temperature compensation unit that guarantees accurate positioning not only in variable temperature environments, but during extended use of ballscrew-driven stages. Using ThermoComp protects your process from real-world positioning conditions even in extreme industrial settings.

PRO165SL/SLE Series SPECIFICATIONS

Mechanical Specifications		PRO165SL/SLE									
Travel		50	100	150	200	250	300	400	500	600	
Accuracy ⁽¹⁾	SL	Standard	±6 μm	±6 μm	±8 μm	±8 μm	±9 μm	±10 µm	±12 μm	±14 μm	±16 µm
		Calibrated	±1 μm	±1.25 µm	±1.5 µm	±1.75 µm	±2 μm	±2.5 µm	±3 µm	±3.5 µm	±4 μm
	SLE	Standard	±3 μm	±4 μm	±6 μm	±8 μm	±9 μm	±10 µm	±12 μm	±14 μm	±15.5 µm
		Calibrated	±1 μm	±1 μm	±1 µm	±1.5 µm	±1.5 μm	±1.5 µm	±1.5 µm	±2 μm	±2 μm
Resolution SL (Min. Incremental Motion) SLE		SL	0.1 μm ₍₂₎ , 1.0 μm ₍₃₎								
		0.05 μm (-E1/-E3 Encoder); 0.2 μm (-E2 Encoder); 1.0 μm (-E4 Encoder)									
Didirectional		SL	±1 μm	±1 μm	±1 μm	±1 µm	±1 µm	±1 µm	±1 µm	±1 μm	±1 µm
		SLE	±0.5 µm	±0.5 µm	±0.5 µm	±0.5 µm	±0.5 µm	±0.5 µm	±0.5 µm	±0.75 μm	±0.75 µm
Horizontal Stra	aightness	(1)	±1.5 µm	±2.5 µm	±3 µm	±4 μm	±5 μm	±6 μm	±8 μm	±9 μm	±10 μm
Vertical Straightness ⁽¹⁾		±1.5 µm	±2.5 µm	±3 µm	±4 μm	±5 μm	±6 μm	±8 μm	±9 μm	±10 µm	
Pitch		19 µrad (3.9 arc sec)	29 µrad (6 arc sec)	29 µrad (6 arc sec)	39 µrad (8 arc sec)	49 μrad (10.1 arc sec)	58 µrad (12 arc sec)	70 µrad (14.4 arc sec)	80 µrad (16.5 arc sec)	90 μrad (18.6 arc sec	
Roll			19 µrad (3.9 arc sec)	29 µrad (6 arc sec)	29 µrad (6 arc sec)	39 µrad (8 arc sec)	49 µrad (10.1 arc sec)	58 µrad (12 arc sec)	70 µrad (14.4 arc sec)	80 µrad (16.5 arc sec)	90 µrad (18.6 arc sec
Yaw			19 µrad (3.9 arc sec)	29 µrad (6 arc sec)	29 µrad (6 arc sec)	39 µrad (8 arc sec)	49 µrad (10.1 arc sec)	58 µrad (12 arc sec)	70 µrad (14.4 arc sec)	80 µrad (16.5 arc sec)	90 µrad (18.6 arc sec
Maximum Spec	ed ⁽⁴⁾		300 mm/s								
Maximum Acc	eleration ⁽⁴	1)	Function of Motor, Amplifier Selection, Payload, and Maximum Axial Load								
		Horizontal	45 kg								
Load Capacity	r(5)	Vertical (Axial)	25 kg								
		Side	45 kg								
Moving Mass		SL	2.3 kg								
(w/ Tabletop)		SLE	2.4 kg								
Stage Mass (N	a Mata-\	SL	5.6 kg	6.1 kg	6.6 kg	7.1 kg	7.6 kg	8.1 kg	9.1 kg	10.1 kg	11.1 kg
olage wass (N	o wotor)	SLE	6.2 kg	6.7 kg	7.3 kg	7.8 kg	8.3 kg	8.9 kg	9.9 kg	11.0 kg	12.0 kg
Material		Anodized Aluminum									
MTBF (Mean Time Between Failure)		20,000 Hours									

- Notes:

 1. Certified with -PL1/PL2 options.

 2. Achieved with Aerotech rotary motor with amplified sine encoder.

 3. Achieved with Aerotech rotary motor with 2500 cnts/rev digital encoder.

 4. Requires the selection of an appropriate amplifier with sufficient voltage and current.

 5. Axis-orientation for on-axis loading is listed.


 6. Specifications are for single-axis systems measured 25 mm above the tabletop. Performance of multi-axis systems is payload and workpoint dependent. Contact factory for multi-axis condications. applications.

 7. Specifications listed are non-foldback kit options. Contact factory for specifications when a foldback kit (-FBx) is used.


Electrical Specifications	
Drive System	Brushless Rotary Servomotor
Feedback (Linear Encoder – SLE Version Only)	Incremental – 1 Vpp and TTL (0.1 μm & 0.5 μm) Output Absolute - EnDat 2.2
Feedback (Rotary Encoder)	Incremental – 1000 lines/rev (1 Vpp) and 2500 lines/rev (TTL)
Maximum Bus Voltage	340 VDC
Limit Switches	5 V, Normally-Closed

Recommended Controller		
Multi-Axis	A3200	Ndrive HLe/Ndrive CP/Ndrive HPe/Npaq
Multi-Axis	Ensemble	Ensemble HLe/Ensemble CP/Ensemble HPe
Single Axis	Soloist	Soloist CP/Soloist HPe


PR0165SL/SLE Series SPECIFICATIONS



Cantilevered load capability of the PRO165SL/SLE.




Measurement data showing successful compensation of thermal related positioning errors at several temperatures using the ThermoComp feature. Results are typical of stage performance with and without ThermoComp.




Measurement data showing successful compensation of internal heating related positioning errors during prolonged operation of a ball screw stage using the ThermoComp feature. Results are typical of ball screw stage performance with and without ThermoComp.


PR0165SL/SLE Series DIMENSIONS




PR0165SL/SLE Series DIMENSIONS



PRO165SL/SLE Series Accessory Tabletop DIMENSIONS





PR0165SL/SLE Series ORDERING INFORMATION

PR0165SL Series Linear, Ball-Screw Stage

	/ B		١.
Travel	IDOL	HOYFIII	١
Havel	INCL	ıuııcu	,
			,

-050	50 mm travel stage
-100	100 mm travel stage
-150	150 mm travel stage
-200	200 mm travel stage
-250	250 mm travel stage
-300	300 mm travel stage
-400	400 mm travel stage
-500	500 mm travel stage
-600	600 mm travel stage

Tabletop (Optional)

-TT1	Tabletop with metric dimension mounting
-TT2	Tabletop with English dimension mounting
-TT3	Accessory tabletop with mounting for select rotary stages
-TT4	Tabletop with metric dimension mounting and wiper brushes
-TT5	Tabletop with English dimension mounting and wiper brushes
-TT6	Accessory tabletop with mounting for select rotary stages and wipers

Motor (Optional)

-M1	BMS100 brushless servomotor and 2500-line TTL encoder
-M2	BMS100 brushless servomotor, 2500-line TTL encoder, and brake
-M3	BMS100 brushless servomotor and 1000-line 1 Vpp encoder
-M4	BMS100 brushless servomotor, 1000-line 1 Vpp encoder, and brake
-M5	BM130 brushless servomotor and 2500-line TTL encoder
-M6	BM130 brushless servomotor, 2500-line TTL encoder, and brake
-M7	BM130 brushless servomotor and 1000-line 1 Vpp encoder
-M8	BM130 brushless servomotor, 1000-line 1 Vpp encoder, and brake

Foldback (Optional)

-FB2 Foldback kit with brake for 0.250 inch diameter shaft NEMA 23 motor	
-FB3 Foldback kit for 0.375 inch diameter shaft NEMA 23 motor	
-FB4 Foldback kit with brake for 0.375 inch diameter shaft NEMA 23 motor	

Note: TT option required for lower axis of XY when a foldback kit is used.

Motor Orientation (Optional)

-2	Bottom cable exit, optional orientation
-3	Left-side cable exit, standard orientation
-4	Top cable exit, optional orientation
-5	Right-side cable exit, optional orientation
-8	Right-side foldback, standard orientation
-12	Left-side foldback, optional orientation

Limits (Required)

-LI1	Normally-closed limit switches; 5 VDC with 9-Pin D connector
-LI2	Normally-open limit switches; 5 VDC with 9-Pin D connector
-LI3	Normally-closed limit switches; 24 VDC with 9-Pin D connector

Coupling (Optional)	
-CP1	Coupling for 0.250 inch diameter shaft
-CP2	Coupling for 0.375 inch diameter shaft

PRO165SL/SLE Series ORDERING INFORMATION

Lifting Hardware (Optional)

-LF	Lifting hardware

Note: Lifting option only available on travels 400 mm and greater. Lifting should never be ordered on the upper-axis of an XY set (only order on lower-axis).

ThermoComp (Optional)

TO ID	TTI C				
-TCMP	Thermo(Comr	integrated thermal	l compensation	single or	lower axis

Note: An A3200 controller must be used with the -TCMP option.

Metrology (Required)

-PL0	No metrology performance plots
-PL1	Metrology, uncalibrated with performance plots
-PL2	Metrology, calibrated (HALAR) with performance plots

Integration (Required)

Aerotech offers both standard and custom integration services to help you get your system fully operational as quickly as possible. The following standard integration options are available for this system. Please consult Aerotech if you are unsure what level of integration is required, or if you desire custom integration support with your system.

-TAS Integration - Test as system

> Testing, integration, and documentation of a group of components as a complete system that will be used together (ex: drive, controller, and stage). This includes parameter file generation, system

tuning, and documentation of the system configuration.

-TAC Integration - Test as components

Testing and integration of individual items as discrete components that ship together. This is typically used for spare parts, replacement parts, or items that will not be used together. These

components may or may not be part of a larger system.

Accessories (To Be Ordered As Separate Line Item)

ALIGN-NPA	Non-precision XY assembly
ALIGN-NPAZ	Non-precision XZ or YZ assembly

ALIGN-PA10 XY assembly; 10 arc sec orthogonality. Alignment to within 7 microns orthogonality for short

travel stages.

ALIGN-PA10Z XZ or YZ assembly with L-bracket; 10 arc second orthogonality. Alignment to within 10 microns

orthogonality for short travel stages.

ALIGN-PA5 XY assembly; 5 arc sec orthogonality. Alignment to within 3 microns orthogonality for short travel

ALIGN-PA5Z XZ or YZ assembly with L-bracket; 5 arc second orthogonality. Alignment to within 5 microns

orthogonality for short travel stages.

HDZ165 Right angle L-bracket for PRO165SL/SLE-050, PRO165SL/SLE-100, and PRO165SL/SLE-150

only.

Note: HDZ bracket requires one of -TT1/-TT2/-TT4/-TT5 when mounting to a PRO stage.

PRO165SLE Series Linear, Ball-Screw Stage with Direct Linear Feedback

Direct Linear Feedback (Required)

	•
-E1	Incremental linear encoder; 1 Vpp
-E2	Incremental linear encoder; 0.1 µm digital TTL output
-E3	Absolute linear encoder; EnDat 2.2
-E4	Incremental linear encoder, 0.5 μm digital TTL output

Travel (Required)

-050	50 mm travel stage
-100	100 mm travel stage
-150	150 mm travel stage
-200	200 mm travel stage
-250	250 mm travel stage
-300	300 mm travel stage

PR0165SL/SLE Series ORDERING INFORMATION

-400	400 mm travel stage
-500	500 mm travel stage
-600	600 mm travel stage

Tabletop (Required)

Tabletop with metric dimension mounting
Tabletop with English dimension Mounting
Accessory tabletop with mounting for select rotary stages
Tabletop with metric dimension mounting and wiper brushes
Tabletop with English dimension mounting and wiper brushes
Accessory tabletop with mounting for select rotary stages and wipers

Motor (Optional)

motor (opinional)	
-M1	BMS100 brushless servomotor and 2500-line TTL encoder
-M2	BMS100 brushless servomotor, 2500-line TTL encoder, and brake
-M3	BMS100 brushless servomotor and 1000-line 1 Vpp encoder
-M4	BMS100 brushless servomotor, 1000-line 1 Vpp encoder, and brake
-M5	BM130 brushless servomotor and 2500-line TTL encoder
-M6	BM130 brushless servomotor, 2500-line TTL encoder, and brake
-M7	BM130 brushless servomotor and 1000-line 1 Vpp encoder
-M8	BM130 brushless servomotor, 1000-line 1 Vpp encoder, and brake
	•

Foldback (Optional)

-FB1	Foldback kit for 0.250 inch diameter shaft NEMA 23 motor
-FB2	Foldback kit with brake for 0.250 inch diameter shaft NEMA 23 motor
-FB3	Foldback kit for 0.375 inch diameter shaft NEMA 23 motor
-FB4	Foldback kit with brake for 0.375 inch diameter shaft NEMA 23 motor

Note: TT option required for lower axis of XY when a foldback kit is used.

Motor Orientation (Optional)

-2	Bottom cable exit, optional orientation
-3	Left-side cable exit, standard orientation
-4	Top cable exit, optional orientation
-5	Right-side cable exit, optional orientation
-8	Right-side foldback, standard orientation
-12	Left-side foldback, optional orientation

Limits (Required)

-LI1	Normally-closed limit switches; 5 VDC with 9-Pin D connector
-LI2	Normally-open limit switches; 5 VDC with 9-Pin D connector
-LI3	Normally-closed limit switches; 24 VDC with 9-Pin D connector

Coupling (Optional)

-CP1	Coupling for 0.250 inch diameter shaft
-CP2	Coupling for 0.375 inch diameter shaft

Lifting Hardware (Optional)

-LF	Lifting hardware
-----	------------------

Note: Lifting option only available on travels 400 mm and greater. Lifting should never be ordered on the upper-axis of an XY set (only order on lower-axis).

ThermoComp (Optional)

TCM (D	TTI C		1	, •	. 1 1	
-TCMP	ThermoComp	integrated the	ermal compen	sation s	angle or l	ower axis
1 01/11	I mermo comp	micogracoa mic	ormar compen	batton, b	migre or i	.O W CI WILLD

Note: An A3200 controller must be used with the -TCMP option.

PRO165SL/SLE Series ORDERING INFORMATION

Metrology (Required)

-PL0	No metrology performance plots
-PL1	Metrology, uncalibrated with performance plots
-PL2	Metrology, calibrated (HALAR) with performance plots

Integration (Required)

Aerotech offers both standard and custom integration services to help you get your system fully operational as quickly as possible. The following standard integration options are available for this system. Please consult Aerotech if you are unsure what level of integration is required, or if you desire custom integration support with your system.

-TAS Integration - Test as system

> Testing, integration, and documentation of a group of components as a complete system that will be used together (ex: drive, controller, and stage). This includes parameter file generation, system

tuning, and documentation of the system configuration.

-TAC Integration - Test as components

> Testing and integration of individual items as discrete components that ship together. This is typically used for spare parts, replacement parts, or items that will not be used together. These

components may or may not be part of a larger system.

Accessories (To Be Ordered As Separate Line Item)

ALIGN-NPA Non-precision XY assembly ALIGN-NPAZ Non-precision XZ or YZ assembly

ALIGN-PA10 XY assembly; 10 arc sec orthogonality. Alignment to within 7 microns orthogonality for short

travel stages.

ALIGN-PA10Z XZ or YZ assembly with L-bracket; 10 arc second orthogonality. Alignment to within 10 microns

orthogonality for short travel stages.

ALIGN-PA5 XY assembly; 5 arc sec orthogonality. Alignment to within 3 microns orthogonality for short travel

ALIGN-PA5Z XZ or YZ assembly with L-bracket; 5 are second orthogonality. Alignment to within 5 microns

orthogonality for short travel stages.

HDZ165 Right angle L-bracket for PRO165SL/SLE-050, PRO165SL/SLE-100, and PRO165SL/SLE-150

only.

Note: HDZ bracket requires one of -TT1/-TT2/-TT4/-TT5 when mounting to a PRO stage.